

## Overview of Charging Characteristics BJ115ba2

No.	Battery voltage	Battery type	Battery capacity	I <sub>1</sub>	U <sub>1</sub>	I <sub>2</sub>	I <sub>3</sub>	U <sub>3</sub>	T <sub>I1 max</sub>	TU <sub>1 max</sub>	TU <sub>3</sub>	Note
0	24 V	FVLA	125 Ah ... 167 Ah	42 A	28.8 V	3.0 A	42 A	27.0 V	5 h	6 h	∞	
1	24 V	FVLA	167 Ah ... 233 Ah	50 A	28.8 V	4.0 A	50 A	27.0 V	6 h	7 h	∞	
2	24 V	FVLA	233 Ah ... 317 Ah	50 A	28.8 V	5.5 A	50 A	27.0 V	8 h	9 h	∞	
3	24 V	FVLA	317 Ah ... 417 Ah	50 A	28.8 V	7.3 A	50 A	27.0 V	11 h	12 h	∞	
4	24 V	FVLA	417 Ah ... 500 Ah	50 A	28.8 V	9.2 A	50 A	27.0 V	11 h	12 h	∞	
5	24 V	VRLA	125 Ah ... 167 Ah	42 A	28.2 V	1.5 A	42 A	27.2 V	5 h	6 h	∞	
6	24 V	VRLA	167 Ah ... 233 Ah	50 A	28.2 V	2.0 A	50 A	27.2 V	6 h	7 h	∞	
7	24 V	VRLA	233 Ah ... 317 Ah	50 A	28.2 V	2.8 A	50 A	27.2 V	8 h	9 h	∞	
8	24 V	VRLA	317 Ah ... 417 Ah	50 A	28.2 V	3.7 A	50 A	27.2 V	11 h	12 h	∞	
9	24 V	VRLA	417 Ah ... 500 Ah	50 A	28.2 V	4.7 A	50 A	27.2 V	11 h	12 h	∞	
A	24 V	VRLA*	125 Ah ... 167 Ah	42 A	28.8 V	1.5 A	42 A	27.6 V	5 h	6 h	∞	
B	24 V	VRLA*	167 Ah ... 233 Ah	50 A	28.8 V	2.0 A	50 A	27.6 V	6 h	7 h	∞	
C	24 V	VRLA*	233 Ah ... 317 Ah	50 A	28.8 V	2.8 A	50 A	27.6 V	8 h	9 h	∞	
D	24 V	VRLA*	317 Ah ... 417 Ah	50 A	28.8 V	3.7 A	50 A	27.6 V	11 h	12 h	∞	
E	24 V	VRLA*	417 Ah ... 500 Ah	50 A	28.8 V	4.7 A	50 A	27.6 V	11 h	12 h	∞	
F	---	---	---	---	---	---	---	---	---	---	---	

**FVLA:** open lead-acid batteries, batteries with water refill

**VRLA:** Valve-regulated lead-acid batteries, maintenance-free wet batteries

**VRLA\*:** Gel batteries, AGM

### Description

1. If a temperature sensor (CTS/TS) is connected and the battery temperature is higher than 45°C, the charging current is reduced to 50%. Only when the battery temperature falls below 40°C again does the charging capacity increase to 100%.
2. If a temperature sensor (CTS/TS) is connected and the battery temperature is higher than 50°C, the charger switches off until the battery temperature is below 45°C.
3. If a temperature sensor (CTS/TS) is connected, the output voltage will be increased by 42 mV per degree if the battery temperature is below 25°C and decreased if the battery temperature is above 25°C.
4. If the time T<sub>I1 max</sub> is exceeded, the charger switches off and the red LED flashes.
5. If the time TU<sub>1 max</sub> is exceeded, the next charging phase begins automatically.

